

## Lock Fitting Instructions



1. Position the lock approx. 75mm up from the bottom of the window and screw into position.



2. Press in the locking bar to mark the point on the frame.



3. Drill a hole using a 12mm bit, (approx 25mm deep), then insert the locking thimble into position.



4. Your lock is now fully installed.

Keylite Roof Windows Ltd.,  
Derryloran Ind. Est.,  
Sandholes Road, Cookstown,  
Co. Tyrone BT80 9LU

Tel: 028 8675 8921  
Fax: 028 8675 8923

E-mail: [info@keylite.co.uk](mailto:info@keylite.co.uk)  
Website: [www.keylite.co.uk](http://www.keylite.co.uk)

Keylite Roof Windows Ltd.,  
Ryder Close, Cadley Hill Ind. Est.,  
Swadlincote,  
South Derbyshire DE11 9EU

Tel: 01283 200150  
Fax: 01283 223352

E-mail: [info@keyliteuk.com](mailto:info@keyliteuk.com)  
Website: [www.keylite.co.uk](http://www.keylite.co.uk)

Keylite Roof Windows Ltd.,  
Unit 30, Rosemount Business Park,  
Ballycoolin Road,  
Finglas, Dublin 11

Tel: 01 822 3333  
Fax: 01 822 3366

E-mail: [info@keylite.ie](mailto:info@keylite.ie)  
Website: [www.keylite.ie](http://www.keylite.ie)