

## Restrictor Fitting Instructions



1. Position the restrictor approx. 100mm up from the bottom of the window and screw into position.



2. Insert restricting bar. This determines its fixing position.



3. Finally, once you have both parts securely fixed, they can now be connected by using the key as shown in point 4.



4. Your restrictor is now fully installed.

Keylite Roof Windows Ltd.,  
Derryloran Ind. Est.,  
Sandholes Road, Cookstown,  
Co. Tyrone BT80 9LU

Tel: 028 8675 8921  
Fax: 028 8675 8923

E-mail: [info@keylite.co.uk](mailto:info@keylite.co.uk)  
Website: [www.keylite.co.uk](http://www.keylite.co.uk)

Keylite Roof Windows Ltd.,  
Ryder Close, Cadley Hill Ind. Est.,  
Swadlincote,  
South Derbyshire DE11 9EU

Tel: 01283 200150  
Fax: 01283 223352

E-mail: [info@keyliteuk.com](mailto:info@keyliteuk.com)  
Website: [www.keylite.co.uk](http://www.keylite.co.uk)

Keylite Roof Windows Ltd.,  
Unit 30, Rosemount Business Park,  
Ballycoolin Road,  
Finglas, Dublin 11

Tel: 01 822 3333  
Fax: 01 822 3366

E-mail: [info@keylite.ie](mailto:info@keylite.ie)  
Website: [www.keylite.ie](http://www.keylite.ie)